



PASSIVE RADIO COMMUNICATIONS COMBINING BACKSCATTER WITH WPT

Nuno Borges Carvalho


Alírio Boaventura; Pedro Cruz; Ricardo Correia;
Ricardo Gonçalves; Hugo Gomes; Daniel Belo
nbcarvalho@ua.pt

COST IC1301



IC1301 – WIPE
Wireless Power Transmission for
Sustainable Electronics


@ www.cost-ic1301.org



WG1: Far-field WPT systems



WG2: Near-field WPT Systems



WG3: Novel Materials and Technologies



WG4: Applications




WG5: Regulation and Society impact



AVEIRO




Fishing City




Salt Farms



Portuguese Venice



Colourful City with a lot of Sun



UNIVERSIDADE DE AVEIRO



IT-AV INTRODUCTION — ORGANIZATION STRUCTURE

➤ IT Sites

Aveiro | Coimbra | Lisboa



➤ Internal Organization




Private Association — Not for Profit — Public good — Exempt from Income Tax

IT - DETI — Universidade de Aveiro (nbcarvalho@ua.pt)








RADIO SYSTEMS

AREAS



PUBLICATIONS









FUNDAMENTAL CONCEPTS OF RADIO SYSTEMS


Class
Transceiver Design

RADIO SYSTEM DRAWBACKS

Limitations



RF RECEIVERS




Super-heterodyne

- Conversion to the digital domain at baseband where it can be processed
- Currently adopted in most radio receivers due to low cost components
- Full on-chip integration is concerned and its design to a specific channel → prevents the expansion of receiving band


Zero-IF

- Signal is selected at RF by BPF, amplified and directly translated to DC
- Evident reduction in number of components → high level integration
- Components much more difficult to design
DC offset, 2nd order IMD products generated around DC



SOFTWARE DEFINED RADIO


Bandpass Sampling Receiver:



- Takes the fact that S/H circuit translates the signal to 1st Nyquist zone
- Digital processing capabilities exploited → multi-band reception
- Mandatory BPF to avoid overlap of signals → tunable or bank of filters
- Analog BW of ADC must include RF carrier

SOFTWARE DEFINED RADIO

S/H circuit translates any input signal to 1st Nyquist zone




$$\text{if } \text{fix}\left(\frac{f_c}{f_s/2}\right) \text{ is } \begin{cases} \text{even,} & f_{\text{fold}} = \text{rem}(f_c, f_s) \\ \text{odd,} & f_{\text{fold}} = f_s - \text{rem}(f_c, f_s) \end{cases}$$


TRANSMITTER

The RF transmitter should also fulfill some requests, for instance:

- Use only the bandwidth that refers to the system standards
- Create low values of harmonic distortion
- Transmit the maximum RF power and simultaneously consume the minimum DC power from the system



TRANSMITTER – ALL DIGITAL




Super-Heterodyne Transmitter

- Digital baseband signals are converted and directly modulated to RF
- Reduced amount of circuitry that allows high level integration
- Carrier leakage, phase gain mismatch, and requires highly linear PA
- With careful design can be employed in SDR TX's


- Signal created in digital domain, modulated at IF, and up-converted
- I/Q modulator working at IF; Output spectrum is far away from LO
- Suffers from similar problems of the receiver case
- Multi-mode implementation is difficult

Direct-Conversion Transmitter




TRANSMITTER — ALL DIGITAL

Visionary solution pointed the use of PWM/ $\Delta\Sigma$ Modulator to create an all-digital TX




- Ideally will consume no DC power and achieve an efficiency of 100%, actually it consumes
- Unfortunately is not possible to design such PA with high efficiency to operate at high frequencies



- Been used in digital versions of EER, known as Polar TX's
- Time misalignment can be compensated in digital domain

TX/RX EXAMPLE

Typical Tx/Rx system



RADIO COMMUNICATIONS

The bright Smart Future



Battery Waste

Huge Amount of Disposals

Large Amount of Energy

RADIO COMMUNICATIONS

These radio architectures are responsible for a large amount of energy consumption....





THE BATTERY PROBLEM

Class
Transceiver Design

BATTERIES

- Batteries take **hundreds of years to decompose**, posing a serious threat to the public health and to the environment.



- ❖ Considering 4 Million habitual residences in Portugal (INE – Censos 2011) and assuming that:


- ✓ 75% of them have a TV equipment
- ✓ 40% have a cable TV Box
- ✓ 30% have a Sound System



- ❖ We end up with an average of **5.8 Millions of remotes in Portugal**
- ❖ Assuming two batteries per remote and two battery changes per year we have a **total of 23.2 Millions batteries being wasted every year !!**

NEXT FRONTIER


WIRELESS THINGS







5G

Mobile communications: from 1G to 5G

Generation	Device	Specifications	People
1G		1G Analog Voice only Low speed No data	
2G		2G Digital Voice and data Low speed No video	
3G		3G Digital Voice and data Medium speed No video	
4G		4G Digital Voice and data High speed No video	
5G		5G Digital Voice and data Very high speed No video	People & Things
5G applications		Smart grids Connected house Health Domestic Entertainment Traffic priority Smart Car Apps beyond navigation Car-to-car communication	
5G is about Communication, Storage, Processing...			




CHALLENGES



ENERGY HARVESTING AND WPT

Energy Harvesting



Ambient Electromagnetic Energy



In both cases: Received RF energy is converted into DC power

Wireless Power Transmission (WPT)

Dedicated and known Transmitter





Rectenna = antenna + rectifier




THE CRYSTAL “GALENA” RADIO

Nuno Borges Carvalho


PRINCIPLE OF OPERATION



PRINCIPLE OF OPERATION





Marconi Type 103 crystal set




BACKSCATTER RADIO

Class
Backscatter Radios

RADIO FREQUENCY IDENTIFICATION - RFID




RADIO FREQUENCY IDENTIFICATION - RFID



PRINCIPLE OF OPERATION

Basic components


- 1) **Reader/Interrogator** – Used for read and store information in Tag
- 2) **Tag/Transponder** – small device which carries data (e.g. Tag ID)
- 3) **Host** - computer running user application



PRINCIPLE OF OPERATION

Passive Tags:



- ❑ Tag has no self battery
- ❑ Tag electronics is remotely powered by the reader
- ❑ Communication made by power reflection (Backscattering)
- ❑ Short range



PRINCIPLE OF OPERATION

Semi-Passive or Battery-Assisted Tags

- Electronics powered by a battery
- communication made by power reflection
- medium range





PRINCIPLE OF OPERATION

Active Tags

- ❑ Tag electronics powered by a battery
- ❑ Tag has a self-oscillator
- ❑ long range
- ❑ conventional radio architecture

ACTIVE




PRINCIPLE OF OPERATION

Active Tags:



Passive Tags




Semi-Passive Tags



PRINCIPLE OF OPERATION

The two main air interface method in today's systems:

- Propagation systems – using Electromagnetic E-fields
- Inductive systems – suing magnetic B-fields





BACKSCATTER



RF RFID Tags are most of the time based on electromagnetic backscatter configurations.

- Backscatter is similar to radars.
- The TAG Antenna reflects part of an incoming electromagnetic wave back to the reader.
- Electromagnetic wave are reflected by most objects that are larger than half the wavelength.
- The backscatter reflection efficiency is maximized for antennas that are resonating with the incoming radar frequency.

The short wavelengths of UHF facilitate the construction of antennas with smaller dimensions and greater efficiency.



UHF RFID



UHF RFID

Typical Reader systems include:




1. RF Transmitter
2. RF Receiver
3. A Digital Signal Processor
4. An Antenna

Typical RF TAG systems include:

1. An Antenna
2. A chip

Typical TAG chip systems include:


1. A Voltage Harvester
2. A digital processor and a simple transmitter



UHF RFID

HIGH-FREQUENCY SYSTEM

1 An integrated circuit sends a digital signal to a transceiver, which generates a radio-frequency signal that is transmitted by a dipole antenna.



2 The electric field of the propagating signal gives rise to a potential difference across the tag's dipole antenna, which causes current to flow into the capacitor; the resulting charge is trapped there by the diode.

3 The voltage across the capacitor turns on the tag's integrated circuit, which sends out its unique identifier code as a series of digital high- and low-voltage levels, corresponding to ones and zeros. The signal moves to the transistor.



6 The reader's transceiver detects the reflected signals and converts them to a digital signal that is relayed to the integrated circuit, where the tag's unique identifier is determined.

5 The variations in the amplitude of the reflected signal, in what is called **backscatter modulation**, correspond to the pattern of the transistor turning on and off.

4 The transistor gets turned on or off by the highs and lows of the digital signal, alternately causing the antenna to reflect back or absorb some of the incident radio-frequency energy from the reader.

UHF RFID

Typical Readers are moving fast to a Software Defined Radio Solution, including a digital part and a RF up-converter and RF down-converter....



ELECTROMAGNETIC BACKSCATTER

Main frequencies for backscatter are at UHF frequencies: 868 MHz (Europe) and 915 MHz (USA); and microwave frequencies: 2.5 GHz and 5.8 GHz

The signal is modulated mainly in ASK and BPSK configurations.

Main use for long-range systems

- Distance between reader and tag $> 1\text{m}$


For higher distances $>15\text{m}$ – backscatter tag's usually use a battery

The tag in this situation is normally put in a stand-by mode for saving battery time, when out of the reader range

The battery of an active backscatter tag never provides power for the transmission of data between tag and reader. The battery is used exclusively for supply power to microchip.

READER ARCHITECTURES


- ✓ Transmitter → ASK Modulator
- ✓ Receiver → Homodyne Receiver



DOWNLINK DATA COMMUNICATION

Downlink: Rader → Tag communication

- ASK modulation



Baseband ASK signal:
$$m(t) = \sum_{k=-\infty}^{+\infty} a_k \delta(t - kT)$$


Transmitted Signal:
$$y_{TX}(t) = m(t) \left\{ A_C \frac{e^{j\omega_c t} + e^{-j\omega_c t}}{2} \right\}$$

RF Carrier

DOWNLINK DATA COMMUNICATION

Downlink: Rader → Tag communication

- ASK modulation



Envelope Demodulation:
$$y(t) = k_2 \left[m(t) \left\{ A_c \frac{e^{j\omega_c t} + e^{-j\omega_c t}}{2} \right\} \right]^2$$

After low-pass filtering, the baseband signal sent by the reader is recovered by the Tag:

$$y_{BB}(t) = \frac{A_c^2 k_2}{2} [m(t)]^2$$


UPLINK DATA COMMUNICATION

Uplink: Tag \rightarrow Reader communication

- Load-Modulated Backscatter (ASK or PSK)

The uplink is a two-step operation:


- ❑ First the reader illuminates the tag with an un-modulated carrier, $x_M(t)$
- ❑ Tag send back information by reflecting power with a time-varying coefficient $\Gamma(t)$



UPLINK DATA COMMUNICATION

Uplink: Tag → Reader communication

- Load-Modulated Backscatter (ASK or PSK)




Transmitted Un-modulated Carrier: $x_M(t) = \left\{ A_c \frac{e^{j\omega_c t} + e^{-j\omega_c t}}{2} \right\}$

Signal Reflected back with tag information: $r(t) = \Gamma(t) \left\{ A_c \frac{e^{j\omega_c t} + e^{-j\omega_c t}}{2} \right\}$

UPLINK DATA COMMUNICATION

Uplink: Tag → Reader communication

- Load-Modulated Backscatter (ASK or PSK)




$$\text{Receiver Mixer Output: } z(t) = \left\{ \Gamma(t) A_c \frac{e^{j\omega_c t} + e^{-j\omega_c t}}{2} \right\} \left\{ A_c \frac{e^{j\omega_c t} + e^{-j\omega_c t}}{2} \right\}$$

Recovered Tag baseband information at the Low-pass filter output:

$$z_{BB}(t) = \frac{1}{2} \Gamma(t) A_c^2$$

COMMERCIAL UHF READER (900MHZ)

Intel® UHF RFID Transceiver R1000 Top Level RF Block Diagram




Source: Intel datasheet

IT - DETI — Universidade de Aveiro (nbcavalho@ua.pt)

INCREASE THE COVERAGE WITHOUT BATTERIES






WIRELESS POWER TRANSMISSION

Class
Wireless Power Transmission


WIRELESS POWER TRANSMISSION FOR PASSIVE RFID

- ✓ **Passive RFID tags have no self-battery**
- ✓ **Energy is harvested from reader RF signal**
- ✓ **RF Energy is converted into DC Power and used as Power Supply**
- ✓ **RF-DC converters are key components of passive RFID tags**

Wireless Power Transmission (WPT) System






WPT Receiver



WIRELESS POWER TRANSMISSION


- ✓ Typically High Speed Schottky Diodes are used in RF-DC converters
- ✓ Commonly used configurations: single-diode detectors (**high RF-DC efficiency**), voltage multipliers (**high voltage**), full-wave rectifiers (current stability), ...
Single-diode Envelope Detector




WIRELESS POWER TRANSMISSION

Half-wave Voltage Multipliers (Charge Pumps)


Voltage Doubler (1-stage)




2-stages



N-stages



Full-wave Rectifiers




de aveiro

telecomunicações

WIRELESS POWER TRANSMISSION

Non-linear Analysis of RF-DC


Any RF-DC Converter can be described by a non-linear Model:



General Model




Diode Non-linear Characteristic (I-V Curve)



WIRELESS POWER TRANSMISSION


Non-linear Analysis of RF-DC



Non-linear part can be approximated by a polynomial memoryless model :

$$y(t) = \sum_{n=0}^N k_n x(t)^n$$

For DC, only the even-order terms are important → Model can be restricted to even order terms and simplified to first 2 terms:



Consider a single tone at the system input:

$$x(t) = B \cos(\omega_1 t + \varphi_1)$$

The output is given by:


$$z(t) = \frac{B^2 k_2}{2} + \frac{6B^4 k_4}{16} + \frac{B^2 k_2}{2} \cos(2\omega_1 t + 2\varphi_1) + \frac{B^4 k_4}{2} \cos(2\omega_1 t + 2\varphi_1) + \frac{B^4 k_4}{8} \cos(4\omega_1 t + 4\varphi_1)$$

After Low-pass filter, the RF components will be eliminated, the only DC component will remain:


$$y_{DC} = \frac{B^2 k_2}{2} + \frac{6B^4 k_4}{16}$$

MODULATION AND CODIFICATION

- ❖ Reader-to-tag link has two goals: Communication and Energy transfer
- ❖ Data communication and Energy transfer can take place simultaneously
- ❖ In such cases the Modulation and Codification must be carefully designed, otherwise the Energy transfer will be degraded
- ❖ For instance: An inappropriate combination of Codification-Modulation with long dead periods (signal off) would lead the tag to fail



Good choice: signal is off for short periods of time




Bad choice: signal is off for long periods of time → At those periods tag has no available energy to operate

MODULATION AND CODIFICATION


Modulation:

- ✓ ASK is the preferred Reader-to-tag modulation because it is simple allowing low-complexity tag design
- ✓ However, pure 100% ASK (OOK) modulation is **not desirable**


100% ASK (OOK), not desirable




e.g. 15% ASK: Signal is never completely switched off



For instance, standard ISO14443-B uses 10% ASK Modulation in downlink






BACKSCATTER RADIO ALTERNATIVES

IMD Passive Radios

1-BIT TRANSPONDER USING HARMONIC EFFECT

- Transmitter illuminates the Tag with a signal at frequency f_1
- Due to Non-linear behavior, tag produces harmonic components at $f_2, 2f_1, \dots, Nf_1$

- TAG = Simple Diode + Antenna




1-BIT TRANSPONDER USING HARMONIC EFFECT

Receiver detects one of the harmonics (e.g. second harmonic, $2f_1$)

- If harmonic is detected → Tag in the field
- If not → No tag in the field

- Used in Anti-theft Systems



NONLINEAR DISTORTION


Non-linear System:

$$y_{NL} = \sum_{k=1}^{+\infty} a_k x(t - \tau_k)^k = a_1 x(t - \tau_1) + a_2 x(t - \tau_2)^2 + \\ + a_3 x(t - \tau_3)^3 + \dots$$


2 tone input:

$$x(t) = b_1 \times \cos(\omega_1 t) + b_2 \times \cos(\omega_2 t)$$

NONLINEAR DISTORTION




NL RFID PROPOSAL



Gomes, H.G. and Carvalho, N.B.C. , “RFID for Location Proposes Based on the Intermodulation Distortion”, Sensors & Transducers Magazine, vol.106, n.7, pp.85-96, July, 2009


NONLINEAR DISTORTION

$$i_D(v_D) = I_S \exp\left(\frac{v_D - R_s i_D}{\eta V_T}\right)$$





$$\delta_{NL}[y(x)] = K_0 + \frac{1}{1!} \frac{d\delta_{NL}[y(x)]}{dx} \bigg|_{x(t)=x_0} (x-x_0) + \frac{1}{2!} \frac{d^2\delta_{NL}[y(x)]}{d^2x} \bigg|_{x(t)=x_0} (x-x_0)^2 + \frac{1}{3!} \frac{d^3\delta_{NL}[y(x)]}{d^3x} \bigg|_{x(t)=x_0} (x-x_0)^3 + \dots$$



BLOCK DIAGRAM




SIGNAL COMPARISON




PROTOTYPE



RESULTS






BACKSCATTER RADIO ALTERNATIVES

Remote Control

BATTERY-LESS REMOTE CONTROL

A battery-free **Remote Control System** is proposed:

- ❖ The Remote requires no battery, based on passive RFID technology
- ❖ Device to be Controlled wirelessly powers the remote control using radio waves
- ❖ The remote control send back information using Backscattering (Power reflection)




Advantages compared to conventional IR technology:


- ✓ **Elimination of costs** associated to battery maintenance and treatment of toxic waste
- ✓ **Long range** and **no line of sight communication** thanks to the use of radio waves
- ✓ **Cost-effective solution** thanks to the use of a low cost RFID technology (UHF)

PROPOSED SOLUTIONS

Option I: Passive Wireless Sensor - alike



Option II: Multi-RFID scheme




Multi-RFID scheme is implemented

- ❑ Several RFID chips are used, each one associated to a key
- ❑ Only the chip associated to the pressed key should be read by the RFID reader to identify the key

MULTI-RFID SCHEME

Operating principle:

- N passive RFID tags associated to N keys/switches
 - By default, no tag responds to reader (silent mode)
 - Once a key is pressed the respective tag is allowed to respond
 - Inactive tags must not interfere with the active one
- Two challenges: **Antenna sharing**, **Tag activation/deactivation**



Tags interconnection (N-port Network)


Port termination

= 0 Ohms by default

= 50 Ohms if user presses the key



MULTI-RFID SCHEME

Example: key # 4 is pressed → RFID4 is routed to the antenna port without interference of idle tags




MULTI-RFID SCHEME - MEASUREMENTS

Switch characterization





Closed Position
inductive behavior →



NC switch

Switch Closed
 $Z_{in} \approx 0$ Ohms →




RADIO SYSTEMS

MULTI-RFID SCHEME - MEASUREMENTS

N-Port Network Simulation and Measurement

Objective: measure Return loss (S_{11} , S_{22}) and Transmission coefficient (S_{21} , S_{12})

Scenario: Only one tag is active, rest of them are short-circuited (inactive)




ADS Model

via-to-ground

P2
via-to-ground



via-to-ground





RADIO SYSTEMS

MULTI-RFID SCHEME - MEASUREMENTS

Remote control prototypes: 3, 4 and 5 keys




Return loss (S11) of 4-key prototype when each key is pressed by the user



- o – key 1 pressed
- x – key 2 pressed
- – key 3 pressed
- < – key 4 pressed


MULTI-RFID SCHEME - MEASUREMENTS

- ✓ The complete system has been successfully tested and validated
- ✓ The remote control system has been integrated in a TV device
- ✓ **CH +**, **CH -**, **Vol +** and **Vol -** functions were implemented.



The prototype is composed by:

- 1) TV
- 2) RFID reader and Computer
- 3) RFID-IR adapter




BACKSCATTER RADIO ALTERNATIVES

Dual Band Backscatter

DESIGNING BACKSCATTER WITH DUAL BAND

Combining WPT and backscatter can actually improve the coverage range in a clever way...




Correia, R.; Borges de Carvalho, N.; Fukuday, G.; Miyaji, A.; Kawasaki, S., "Backscatter wireless sensor network with WPT capabilities," in *Microwave Symposium (IMS), 2015 IEEE MTT-S International*, vol., no., pp.1-4, 17-22 May 2015

DESIGNING BACKSCATTER WITH DUAL BAND

The backscatter is designed so that the input matching network is dual at harmonics

...





Correia, R.; Borges de Carvalho, N.; Fukuday, G.; Miyaji, A.; Kawasaki, S., "Backscatter wireless sensor network with WPT capabilities," in *Microwave Symposium (IMS), 2015 IEEE MTT-S International*, vol., no., pp.1-4, 17-22 May 2015

DESIGNING BACKSCATTER WITH DUAL BAND

The backscatter is designed so that the input matching network is dual at harmonics

...




Correia, R.; Borges de Carvalho, N.; Fukuday, G.; Miyaji, A.; Kawasaki, S., "Backscatter wireless sensor network with WPT capabilities," in *Microwave Symposium (IMS), 2015 IEEE MTT-S International*, vol., no., pp.1-4, 17-22 May 2015

DESIGNING BACKSCATTER WITH DUAL BAND


The backscatter is designed so that the input matching network is dual at harmonics

...





Correia, R.; Borges de Carvalho, N.; Fukuday, G.; Miyaji, A.; Kawasaki, S.,
"Backscatter wireless sensor network with WPT capabilities," in *Microwave
Symposium (IMS), 2015 IEEE MTT-S International* , vol., no., pp.1-4, 17-22 May
2015

PASSIVE COMMUNICATIONS




RADIO SYSTEMS

PASSIVE COMMUNICATIONS



RADIO SYSTEMS

FUTURE VISION



**CALL FOR
PAPERS**

IEEE



WPTC 2016

WIRELESS POWER TRANSFER CONFERENCE

Aveiro @ Portugal

May 2016

IEEE WPTC 2016

www.wptc2016.org

May 7-8, 2016 Aveiro – Portugal
- Europe



IT - DETI — Universidade de Aveiro (nbcavalho@ua.pt)



RADIO SYSTEMS

QUESTIONS?

